




Dekors für Silber-Gehäuse

Decorations for silver cases — Décorations pour boîtes en argent
Decoraciones para cajas de plata




No. 10



No. 11




No. 12



No. 13



No. 14



No. 18



No. 19



No. 20



No. 21




Dekors für Goldplaqué-Gehäuse


Decorations for gold filled cases — Décorations pour boîtes en plaqué or
Decoraciones para cajas en plaqué oro



No. 37




No. 34




No. 45




No. 46



No. 411



No. 426



No. 427

Dekor No. 34, 37, 46 nur für die Uhren
No. 140/100-102, 150/104-105 lieferbar

Decorations Nos. 34, 37, 46 can be supplied
only for the watches Nos. 140/100-102,
150/104-105

Les décorations No. 34, 37, 46 ne
sont livrées que pour les montres
No. 140/100-102, 150/104-105

Las decoraciones No. 34, 37, 46 se
hacen solamente para los relojes
No. 140/100-102, 150/104-105

