

72/8225

Goldgehäuse 14 Karat, Goldblatt, Werk 672.
Gold case 14 ct., golden dial, movement 672.
Boîtier or 14 cts, cadran or, mouvement 672.
Caja de oro 14 quilates, esfera dorada, máquina 672.
Cassa d'oro di 14 carati, quadrante d'oro, movimento 672.

72/8224

Goldgehäuse 14 Karat, Goldblatt, Werk 672.
Gold case 14 ct., golden dial, movement 672.
Boîtier or 14 cts, cadran or, mouvement 672.
Caja de oro 14 quilates, esfera dorada, máquina 672.
Cassa d'oro di 14 carati, quadrante d'oro, movimento 672.

72/8228

Goldgehäuse 14 Karat, blaues Zifferblatt, Werk 672.
Gold case 14 ct., blue dial, movement 672.
Boîtier or 14 cts, cadran bleu, mouvement 672.
Caja de oro 14 quilates, esfera azul, máquina 672.
Cassa d'oro di 14 carati, quadrante blu, movimento 672.

72/8227

Goldgehäuse 14 Karat, braunes Blatt, Goldzeichen, Werk 672.
Gold case 14 ct., brown dial, golden marks, movement 672.
Boîtier or 14 cts, cadran marron, marques or, mouvement 672.
Caja de oro 14 quilates, esfera marrón, signos dorados, máquina 672.
Cassa d'oro di 14 carati, quadrante bruno, indici d'oro, movimento 672.

72/5752

Plaquégehäuse, Plaquéband, champagnerfarbenes Zifferblatt, Sonnenschliff, Werk 672.
Gold-plated case and bracelet, champagne-coloured dial, solar-grinding, movement 672.
Boîtier plaqué, bracelet plaqué, cadran champagne, satiné soleil, mouvement 672.
Caja chapada, pulsera chapada, esfera color champán, rectificado solar, máquina 672.
Cassa placcata, braccialeto placcato, quadrante soleil colore crema, movimento 672.

72/5764

Plaquégehäuse, Plaquéband, champagnerfarbenes Zifferblatt, Sonnenschliff, Werk 672.
Gold-plated case and bracelet, champagne-coloured dial, solar-grinding, movement 672.
Boîtier plaqué, bracelet plaqué, cadran champagne, satiné soleil, mouvement 672.
Caja chapada, pulsera chapada, esfera color champán, rectificado solar, máquina 672.
Cassa placcata, braccialeto placcato, quadrante soleil colore crema, movimento 672.

72/8229

Goldgehäuse 14 Karat, Zifferblatt weiß Email, schwarz bedruckt, Werk 672.
Case 14 ct. gold, white enamel dial, black printed, movement 672.
Boîtier or 14 cts, cadran émail blanc, imprimé noir, mouvement 672.
Caja oro 14 quilates, esfera esmaltada blanca, impresión negra, máquina 672.
Cassa d'oro di 14 carati, quadrante bianco di smalto, impressione nera, movimento 672.

72/5910

Plaquégehäuse, Plaquéband, Silberblatt, Sonnenschliff, Werk 672.
Gold-plated case and bracelet, silver dial, solar-grinding, movement 672.
Boîtier plaqué, bracelet plaqué, cadran argenté, satiné soleil, mouvement 672.
Caja chapada, pulsera chapada, esfera plateada, rectificado solar, máquina 672.
Cassa placcata, braccialeto placcato, quadrante soleil d'argento, movimento 672.

72/8226

Goldgehäuse 14 Karat, Silberblatt, Sonnenschliff, Werk 672.
Gold case 14 ct., silver dial, solar-grinding, movement 672.
Boîtier or 14 cts, cadran argenté, satiné soleil, mouvement 672.
Caja de oro 14 quilates, esfera plateada, rectificado solar, máquina 672.
Cassa d'oro di 14 carati, quadrante soleil d'argento, movimento 672.

72/8005

Goldgehäuse 14 Karat, champagnerfarbenes Zifferblatt, Werk 672.
Gold case 14 ct., champagne-coloured dial, movement 672.
Boîtier or 14 cts, cadran champagne, mouvement 672.
Caja de oro 14 quilates, esfera color champán, máquina 672.
Cassa d'oro di 14 carati, quadrante color crema, movimento 672.

72/8006

Goldgehäuse 14 Karat, Silberblatt, Sonnenschliff, Werk 672.
Gold case 14 ct., silver dial, solar-grinding, movement 672.
Boîtier or 14 cts, cadran argenté, satiné soleil, mouvement 672.
Caja de oro 14 quilates, esfera plateada, rectificado solar, máquina 672.
Cassa d'oro di 14 carati, quadrante soleil d'argento, movimento 672.



72/8225




72/8224



72/8228



72/8227



72/5764



72/8229



72/5752



72/8226



72/8005



72/5910



72/8006