

77/9959

Gehäuse und Band 14 Karat Weißgold, 14,9 g, 18 Brill. = 0,34 Karat, Zifferblatt matt versilbert, facettierte Weißreliefzeichen, Werk 661.

Case and bracelet 14 ct. white gold, 14,9 g, 18 brill. = 0,34 ct., mat silvered dial, faceted white raised marks, movement 661.

Boîtier et bracelet or blanc 14 carats, 14,9 g, 18 brill. = 0,34 carats, cadran argenté mat, marques en relief blanches à facettes, mouvement 661.

Caja y pulsera oro blanco 14 quilates, 14,9 g, 18 brillantes 0,34 quilate, esfera plateada mate, signos de relieve blancos con facetas, máquina 661.

Cassa e bracciale d'oro bianco di 14 carati, 14,9 g, 18 brillanti di 0,34 carati, quadrante d'argento mat, indici bianchi in rilievo, sfaccettati, movimento 661.

72/9664

Goldgehäuse mit Goldband 14 Karat, 32,1 g, champagnerfarbenes Zifferblatt, Sonnenschiff, Werk 672.

Gold case and bracelet 14 ct., 32,1 g, champagne-coloured dial, solar-grinding, movement 672.

Boîtier et bracelet or 14 cts, 32,1 g, cadran champagne, satiné soleil, mouvement 672.

Caja de oro con pulsera de oro 14 quilates, 32,1 g, esfera color champán, rectificado solar, máquina 672.

Cassa e bracciale d'oro di 14 carati, 32,1 g, quadrante soleil colore crema, movimento 672.

72/9970

Gehäuse Weißgold 14 Karat, 29,5 g, Silberblatt, Werk 672.

White gold case 14 ct., 29,5 g, silver dial, movement 672.

Boîtier or blanc 14 cts, 29,5 g., cadran argenté, mouvement 672.

Caja de oro blanco 14 quilates, 29,5 g, esfera plateada, máquina 672.

Cassa d'oro bianco di 14 carati, 29,5 g, quadrante d'argento, movimento 672.

77/9958

Gehäuse und Band 14 Karat Weißgold, 17,8 g, 4 Brill. = 0,07 Karat, Zifferblatt Silber, strukturiert, geschnittene Weißreliefzeichen, Werk 672.

Case and bracelet 14 ct. white gold 17,8 g, 4 brill. = 0,07 ct., embossed silver dial, cut white raised marks, movement 672.

Boîtier et bracelet or blanc 14 carats, 17,8 g, 4 brill. = 0,07 carats, cadran argent structuré, marques en relief blanches, mouvement 672.

Caja y pulsera oro blanco 14 quilates, 17,8 g, 4 brillantes 0,07 quilate, esfera plateada estructurada, signos de relieve blancos, máquina 672.

Cassa e bracciale d'oro bianco di 14 carati, 17,8 g, 4 brillanti di 0,07 carati, quadrante con struttura in argento, indici bianchi tagliati in rilievo, movimento 672.

72/9667

Goldgehäuse mit Goldband 14 Karat, 35,7 g, Silberblatt, Werk 672.

Gold case and bracelet 14 ct., 35,7 g, silver dial, movement 672.

Boîtier or, bracelet or 14 cts, 35,7 g, cadran argenté, mouvement 672.

Caja de oro con pulsera de oro 14 quilates, 35,7 g, esfera plateada, máquina 672.

Cassa e bracciale d'oro di 14 carati, 35,7 g, quadrante d'argento, movimento 672.

72/9668

Goldgehäuse mit Goldband 14 Karat, 38,4 g, Goldblatt, Werk 672.

Gold case and bracelet 14 ct., 38,4 g, golden dial, movement 672.

Boîtier et bracelet or 14 cts, 38,4 g, cadran or, mouvement 672.

Caja de oro con pulsera de oro 14 quilates, 38,4 g, esfera dorada, máquina 672.

Cassa e bracciale d'oro di 14 carati, 38,4 g, quadrante d'oro, movimento 672.

72/9342

Goldgehäuse 14 Karat, 31,9 g, Goldblatt, Werk 672.

Gold case 14 ct., 31,9 g, golden dial, movement 672.

Boîtier or 14 cts, 31,9 g, cadran or, mouvement 672.

Caja de oro 14 quilates, 31,9 g, esfera dorada, máquina 672.

Cassa d'oro di 14 carati, 31,9 g, quadrante d'oro, movimento 672.

77/9910

Gehäuse und Band 14 Karat Weißgold, 14,8 g, Silberblatt, Sonnenschiff, Werk 661.

Case and bracelet 14 ct., white gold, 14,8 g, silver dial, solar-grinding, movement 661.

Boîtier et bracelet or blanc 14 cts, 14,8 g, cadran argenté, satiné soleil, mouvement 661.

Caja y pulsera oro blanco 14 quilates, 14,8 g, esfera plateada, rectificado solar, máquina 661.

Cassa e bracciale d'oro bianco di 14 carati, 14,8 g, quadrante soleil d'argento, movimento 661.

72/9471

Goldgehäuse mit Goldband 14 Karat, 33,5 g, Goldblatt, Werk 672.

Gold case and bracelet 14 ct., 33,5 g, golden dial, movement 672.

Boîtier et bracelet or 14 cts, 33,5 g, cadran or, mouvement 672.

Caja de oro con pulsera de oro 14 quilates, 33,5 g, esfera dorada, máquina 672.

Cassa e bracciale d'oro di 14 carati, 33,5 g, quadrante d'oro, movimento 672.

72/9902

Goldgehäuse mit Goldband, Weißgold 14 Karat, 24,6 g, dunkelblaues Zifferblatt, Sonnenschiff, Werk 672.

White gold case and bracelet 14 ct., 24,6 g, dark-blue dial, solar-grinding, movement 672.

Boîtier et bracelet or blanc 14 cts, 24,6 g, cadran bleu foncé, satiné soleil, mouvement 672.

Caja y pulsera de oro blanco 14 quilates, 24,6 g, esfera azul oscuro, rectificado solar, máquina 672.

Cassa e bracciale d'oro bianco di 14 carati, 24,6 g, quadrante soleil blu scuro, movimento 672.

72/9403

Goldgehäuse mit Goldband 14 Karat, 28,7 g, Silberblatt, Sonnenschiff, Werk 672.

Gold case and bracelet 14 ct., 28,7 g, silver dial, solar-grinding, movement 672.

Boîtier or, bracelet or 14 cts, 28,7 g, cadran argenté, satiné soleil, mouvement 672.

Caja de oro con pulsera 14 quilates, 28,7 g, esfera plateada, rectificado solar, máquina 672.

Cassa e bracciale d'oro di 14 carati, 28,7 g, quadrante soleil d'argento, movimento 672.



77/9959



77/9958



77/9910



72/9664



72/9667



72/9471



72/9970




72/9668



72/9902



72/9342



72/9403

72/9403