

68/0260


Gehäuse verchromt, Edelstahlboden, Zifferblatt blau, Werk 674.  
Chromed case, stainless steel back, blue dial, no. 674 movement.  
Boîtier chromé, fond acier inoxydable, cadran bleu, mouvement 674.  
Caja cromada, fondo de acero fino, esfera azul, máquina 674.  
Cassa cromata, fondo d'acciaio inossidabile, quadrante blu, movimento 674.

68/0900


Gehäuse verchromt, Edelstahlboden, wasserdicht, Zifferblatt silber, 12 gedruckte Zahlen, Werk 674.  
Chromed case, stainless steel back, waterproof, silvered dial, 12 printed figures, no. 674 movement.  
Boîtier chromé, fond acier inoxydable, étanche, cadran argenté, 12 chiffres imprimés, mouvement 674.  
Caja cromada, fondo de acero fino, impermeable, esfera plateada, 12 números impresos, máquina 674.  
Cassa cromata, fondo d'acciaio inossidabile, impermeabile, quadrante d'argento, 12 cifre stampate, movimento 674.

68/0361


Gehäuse verchromt, Edelstahlboden, Leuchtpunkte, Leuchtzeiger, wasserdicht, Zifferblatt silber, Werk 674.  
Chromed case, stainless steel back, luminous dots and hands, waterproof, silvered dial, no. 674 movement.  
Boîtier chromé, fond acier inoxydable, points et aiguilles phosphorescents, étanche, cadran argenté, mouvement 674.  
Caja cromada, fondo de acero fino, puntos y agujas luminosos, impermeable, esfera plata, máquina 674.  
Cassa cromata, fondo d'acciaio inossidabile, punti e lancette luminosi, impermeabile, quadrante d'argento, movimento 674.

68/0521


Gehäuse verchromt, Edelstahlboden, Leuchtpunkte, Leuchtzeiger, Zifferblatt weiß matt, Werk 674.  
Chromed case, stainless steel back, luminous dots and hands, mat white dial, no. 674 movement.  
Boîtier chromé, fond acier inoxydable, points et aiguilles phosphorescents, cadran mat blanc, mouvement 674.  
Caja cromada, fondo de acero fino, puntos y agujas luminosos, esfera blanca mate, máquina 674.  
Cassa cromata, fondo d'acciaio inossidabile, punti e lancette luminosi, quadrante bianco mat, movimento 674.

68/1503


Gehäuse verchromt, Edelstahlboden, Zifferblatt weiß, 12 gedruckte Zahlen, Werk 674.  
Chromed case, stainless steel back, white dial, 12 printed figures, no. 674 movement.  
Boîtier chromé, fond acier inoxydable, cadran blanc, 12 chiffres imprimés, mouvement 674.  
Caja cromada, fondo de acero fino, esfera blanca, 12 números impresos, máquina 674.  
Cassa cromata, fondo d'acciaio inossidabile, quadrante bianco, 12 cifre stampate, movimento 674.

68/0450


Gehäuse verchromt, Edelstahlboden, Leuchtpunkte, Leuchtzeiger, wasserdicht, Zifferblatt silber, Werk 674.  
Chromed case, stainless steel back, luminous dots and hands, waterproof, silvered dial, no. 674 movement.  
Boîtier chromé, fond acier inoxydable, points et aiguilles phosphorescents, étanche, cadran argenté, mouvement 674.  
Caja cromada, fondo de acero fino, puntos y agujas luminosos, impermeable, esfera plata, máquina 674.  
Cassa cromata, fondo d'acciaio inossidabile, punti e lancette luminosi, quadrante d'argento, movimento 674.

68/0522


Gehäuse verchromt, Edelstahlboden, Leuchtzahlen, Leuchtzeiger, Zifferblatt schwarz, Werk 674.  
Chromed case, stainless steel back, luminous figures and hands, black dial, no. 674 movement.  
Boîtier chromé, fond acier inoxydable, points et aiguilles phosphorescents, cadran noir, mouvement 674.  
Caja cromada, fondo de acero fino, números y agujas luminosos, esfera negra, máquina 674.  
Cassa cromata, fondo d'acciaio inossidabile, punti e lancette luminosi, quadrante nero, movimento 674.

68/1701


Gehäuse verchromt, Edelstahlboden, wasserdicht, Zifferblatt schwarz matt, Leuchtpunkte, Leuchtzeiger, Werk 674.  
Chromed case, stainless steel back, waterproof, mat black dial, luminous dots and hands, no. 674 movement.  
Boîtier chromé, fond acier inoxydable, étanche, cadran mat noir, points et aiguilles phosphorescents, mouvement 674.  
Caja cromada, fondo de acero fino, impermeable, esfera negra mate, puntos y agujas luminosos, máquina 674.  
Cassa cromata, fondo d'acciaio inossidabile, impermeabile, quadrante nero mat, punti e lancette luminosi, movimento 674.



68/0260



68/0361



68/0450



68/0521



68/0522



68/0900



68/1503



68/1701