

79/8013

Goldbanduhr 14 Karat = 16,75 g, Zifferblatt champagnerfarben, Werk 672.
Gold case and bracelet, 14 ct. = 16,75 g, champagne-coloured dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 16,75 g, cadran champagne, mouvement 672.
Reloj pulsera oro 14 quilates = 16,75 g, esfera color champán, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 16,75 g, quadrante colore crema, movimento 672.

79/8014

Goldbanduhr 14 Karat = 17,31 g, Zifferblatt goldfarben, Werk 672.
Gold case and bracelet, 14 ct. = 17,31 g, golden dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 17,31 g, cadran doré, mouvement 672.
Reloj pulsera oro 14 quilates = 17,31 g, esfera dorada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 17,31 g, quadrante color d'oro, movimento 672.

79/8015

Goldbanduhr 14 Karat = 19,61 g, Zifferblatt goldfarben, Werk 672.
Gold case and bracelet, 14 ct. = 19,61 g, golden dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 19,61 g, cadran doré, mouvement 672.
Reloj pulsera oro 14 quilates = 19,61 g, esfera dorada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 19,61 g, quadrante color d'oro, movimento 672.

79/8016

Goldbanduhr 14 Karat = 20,0 g, Zifferblatt goldfarben, Werk 672.
Gold case and bracelet, 14 ct. = 20,0 g, golden dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 20,0 g, cadran doré, mouvement 672.
Reloj pulsera oro 14 quilates = 20,0 g, esfera dorada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 20,0 g, quadrante color d'oro, movimento 672.

79/8017

Goldbanduhr 14 Karat = 20,07 g, Zifferblatt silber, Werk 672.
Gold case and bracelet, 14 ct. = 20,07 g, silver dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 20,07 g, cadran argenté, mouvement 672.
Reloj pulsera oro 14 quilates = 20,07 g, esfera plateada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 20,07 g, quadrante d'argento, movimento 672.

79/8018

Goldbanduhr 14 Karat = 20,20 g, Zifferblatt goldfarben, Werk 672.
Gold case and bracelet, 14 ct. = 20,20 g, golden dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 20,20 g, cadran doré, mouvement 672.
Reloj pulsera oro 14 quilates = 20,20 g, esfera dorada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 20,20 g, quadrante color d'oro, movimento 672.

79/8019

Goldbanduhr 14 Karat = 19,04 g, Zifferblatt goldfarben, Werk 672.
Gold case and bracelet, 14 ct. = 19,04 g, golden dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 19,04 g, cadran doré, mouvement 672.
Reloj pulsera oro 14 quilates = 19,04 g, esfera dorada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 19,04 g, quadrante color d'oro, movimento 672.

79/8021

Goldbanduhr 14 Karat = 21,0 g, Zifferblatt silber, Werk 672.
Gold case and bracelet, 14 ct. = 21,0 g, silver dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 21,0 g, cadran argenté, mouvement 672.
Reloj pulsera oro 14 quilates = 21,0 g, esfera plateada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 21,0 g, quadrante d'argento, movimento 672.

79/8022

Goldbanduhr 14 Karat = 21,3 g, Zifferblatt goldfarben, Werk 672.
Gold case and bracelet, 14 ct. = 21,3 g, golden dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 21,3 g, cadran doré, mouvement 672.
Reloj pulsera oro 14 quilates = 21,3 g, esfera dorada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 21,3 g, quadrante color d'oro, movimento 672.

79/8024

Goldbanduhr 14 Karat = 21,1 g, Zifferblatt goldfarben, Werk 672.
Gold case and bracelet, 14 ct. = 21,1 g, golden dial, no. 672 movement.
Boîtier et bracelet or, 14 cts. = 21,1 g, cadran doré, mouvement 672.
Reloj pulsera oro 14 quilates = 21,1 g, esfera dorada, máquina 672.
Cassa e braccialeto d'oro di 14 carati = 21,1 g, quadrante color d'oro, movimento 672.



79/8013



79/8014



79/8015



79/8016



79/8017



79/8018



79/8019



79/8021



79/8022



79/8024

